

1965

**CHEVROLET—CHEVELLE—CHEVY II—CORVAIR—  
GREENBRIER—CHEVROLET TRUCKS  
ACCESSORIES INSTALLATION  
REFERENCE MANUAL**



*Good Installations and  
Product Knowledge Helps Sell Accessories  
and Satisfy Customers*

**KNOW YOUR PRODUCT**



# 1965

## CHEVROLET—CHEVELLE—CHEVY II—CORVAIR— GREENBRIER—CHEVROLET TRUCKS ACCESSORIES INSTALLATION REFERENCE MANUAL



A reference manual to assist dealer service managers in training new car get ready men and mechanics in the proper installation of accessories. Accessories that are installed correctly will fulfill their purpose, function and give satisfactory service to the car owner.

*All illustration and specifications contained in this literature are based on the latest product information available at the time of publication approval. The right is reserved to make changes at any time without notice in prices, colors, materials, equipment, specifications and models, and also to discontinue models.*

CHEVROLET MOTOR DIVISION,  
GENERAL MOTORS CORPORATION  
DETROIT MICHIGAN 48202

© 1964 CHEVROLET MOTOR DIVISION  
GENERAL MOTORS CORPORATION



## ALPHABETICAL INDEX

Description	Part No.	Page No.	Flat Rate Hours
ADAPTER - W/S Washer - All trucks w/heavy duty air clng. .	986186	521	-
AIR CONDITIONING - COMPRESSOR Mounting for 4 & 6 cyl. .	ALL	9-15	-
AIR CONDITIONING - COMPRESSOR Mounting for 8 cyl. . . .	ALL	16-27	-
AIR CONDITIONING - CUSTOM - CHEVROLET . . . . .	ALL	28-42	7.5
AIR CONDITIONING - CUSTOM - CHEVELLE . . . . .	ALL	43-54	7.5
AIR CONDITIONING - CUSTOM - CHEVY II . . . . .	ALL	55-72	7.5
AIR CONDITIONING - CORVAIR (Instructions not available at publication date)			
AIR CONDITIONING - TRUCK (Adapter) . . . . .	986241	73-75	-
AIR CONDITIONING - ALL WEATHER TRUCK . . . . .	ALL	76-103	9.0
ANTENNA - Right Front - Chevrolet . . . . .	986097	104-105	-
ANTENNA - Right Rear - Chevrolet . . . . .	986103	106-108	-
ANTENNA - Right Front - Chevelle . . . . .	986204	109-110	-
ANTENNA - Right Rear - Chevelle . . . . .	986208-986319	111-113	-
ANTENNA - Right Front - Chevy II . . . . .	986309	114-115	.6
ANTENNA - Right Rear - Chevy II . . . . .	986307	116-118	.6
ANTENNA - Right Front - Corvair . . . . .	986114	119-120	-
ANTENNA - Right Rear - Corvair . . . . .	986120	121-123	-
ANTENNA - Left Rear - Corvette Electric . . . . .	986305	124-127	.7
ANTENNA - Right Front - Truck Except Tilt Cab . . . . .	986301	128-129	.4
ANTENNA - Right Front - Truck Tilt Cab . . . . .	985473	130-131	.4
ANTENNA - Right Front - Chevy Van . . . . .	985917	132-133	.3
ANTENNA - Right Front - Corvair 95 . . . . .	985444	134-135	1.0
BELT - Seat - Front - All Passenger Cars . . . . .	ALL	136-139	.4
BELT - Seat - Rear - All Passenger Cars . . . . .	ALL	140-145	.4
BELT - Seat - Front - All Truck . . . . .	ALL	146-154	.6
BRAKE - Power - Chevrolet . . . . .	986044	155-157	.8
BRAKE - Power - Chevelle . . . . .	986351	158-160	.8
BRAKE - Power - Chevy II . . . . .	986352	161-162	.8
BRAKE - Power - Truck . . . . .	985936	163-165	1.3
CARRIER - Roof Luggage - 5 Stanchion - Chevrolet Station Wgn . . . . .	986134	166-167	1.4
CARRIER - Roof Luggage - 5 Stanchion - Chevelle Station Wgn . . . . .	985806	168-169	1.4
CARRIER - Roof Luggage - 4 Stanchion - Chevy II . . . . .	986326	170-171	1.4
CARRIER - Roof Luggage - 6 Stanchion - Corvair 95 . . . . .	988398	171	1.4
CLOCK - Electric - Instrument Panel Mtg. All Exc. Corvair and Corvette . . . . .	986311	173-177	.4
CLOCK - Electric - Instrument Cluster - Chevrolet . . . . .	986274	178	.4
CLOCK - Electric - Instrument Cluster - Chevelle . . . . .	986256	179	.5
CLOCK - Electric - Instrument Cluster - Chevy II . . . . .	986275	180	.5
CLOCK - Electric - Instrument Cluster - Corvair . . . . .	986231	181	.5
CLUTCH - Modulated Fan . . . . .	985355-986067	182	.3
COMPASS - All Vehicles . . . . .	986298	183	-
CONTROL - Guidematic - Headlamp - Chevrolet . . . . .	986299	184-185	1.6
COVER - Roof Luggage Carrier - Chevrolet - Chevelle & Chevy II . . . . .	985947	186	.3
COVER - Wheel 14 and 13" . . . . .	ALL	187	.4



## ALPHABETICAL INDEX (Continued)

Description	Part No.	Page No.	Flat Rate Hours
DEFROSTER - Rear Window - Chevrolet - Chevelle & Chevy II . . . . .	986094	188-190	.4
DISPENSER - Tissue - All Except Truck and Corvette . . . . .	986045	191	.3
FRAMES - License - Chevrolet - Chevelle and Chevy II . . . . .	986080	192-193	.2
GUARD - Front Bumper Rail - Chevrolet . . . . .	986185	194	.8
GUARD - Rear Bumper - Chevrolet Except Station Wagon . . . . .	986184	195	-
GUARD - Front Bumper - Chevelle . . . . .	986124	196	.2
GUARD - Rear Bumper - Chevelle Except Station Wagon . . . . .	985761	197	.2
GUARD - Grille - Chevy II . . . . .	985435	198	.3
GUARD - Bumper - Rear - Chevy II . . . . .	985302	199	.2
GUARD - Bumper - Front and Rear - Corvair . . . . .	986138-986139	200	.3
GUARD - Bumper - Front - Truck . . . . .	985501-985502	201	.2
GUARD - Front or Rear - Corvair 95 . . . . .	985070-988373	202	.2
GUARD - Brush Type - C-10-20-30 Truck . . . . .	985866	203	1.0
GUARD - Brush Type - 1 1/2 Ton Except L Truck . . . . .	985867	204-205	1.0
GUARD - Door Edge - Chevrolet . . . . .	986106-986111	206	.2
GUARD - Door Edge - Chevelle . . . . .	985849-985850	207	.2
GUARD - Door Edge - Chevy II . . . . .	985163-985164	208	.2
GUARD - Door Edge - Corvair . . . . .	986039-986038	209	.2
GUARD - Gasoline Filler Door - Station Wgn. Chevy . . . . .	986241	210	.2
GUARD - Gasoline Filler Door - Corvair . . . . .	986078	211	.2
GUARD - Mud Flap - Station Wagon - Chevy, Chevelle, & Chevy II . . . . .	986135	212-214	.4
GUARD - Mud Flap - Dual Wheels - Truck . . . . .	987226	215-218	.4
HARNES - Accessories Wiring - Corvair 95 . . . . .	985350	219	.4
HARNES - Trailer Wiring - All Except Truck . . . . .	986336-986337	220-222	.4
HEATER & DEFROSTER - Deluxe - Truck Except Tilt Cab . . . . .	985769	223-229	1.6
HEATER & DEFROSTER - Thriftair - Except Tilt Cab . . . . .	985991	230-236	1.2
HEATER & DEFROSTER - Deluxe Air - Corvair 95 . . . . .	985698	237-251	5.0
HEATER & DEFROSTER - Deluxe Gasoline - Corvair 95 . . . . .	985648	252-263	3.9
HEATER & DEFROSTER - Chevy Van . . . . .	986342	264-267	1.9
HEATER & DEFROSTER - Truck - Suburban Carry-All . . . . .	986346	268-270	1.2
HITCH-TRAILER - Chevrolet Except Station Wagon . . . . .	986215	271	1.0
HITCH-TRAILER - Chevrolet - Station Wagon . . . . .	986216	272	1.0
HITCH-TRAILER - Chevelle Except Station Wagon . . . . .	985744	273-274	1.0
HITCH-TRAILER - Chevelle - Station Wagon . . . . .	985745	275-276	1.0
HITCH-TRAILER - Chevy II Except Station Wagon . . . . .	985988	277-278	1.0
HITCH-TRAILER - Chevy II - Station Wagon . . . . .	985989	279-280	1.0
HITCH-TRAILER - Corvair . . . . .	986244	281	1.0
HORN - Tri-Volume - Chevrolet, Chevelle & Chevy II . . . . .	986265	282-284	.3
HORN - Air Truck . . . . .	985959	285-288	1.2
HORN - Low Note - Truck . . . . .	985809	289	.3
HORN & COMPRESSOR - Air Truck . . . . .	986285	290-296	.6



## ALPHABETICAL INDEX (Continued)

Description	Part No.	Page No.	Flat Rate Hours
LAMP - Ash Tray - All Except Truck and Corvette . . . . .	986239	297-298	.6
LAMP - Back Up - Chevrolet Except Station Wagon . . . . .	986296	299	.6
LAMP - Back Up - Chevrolet - Station Wagon . . . . .	986297	300-301	.6
LAMP - Back Up - Chevelle Except Station Wagon . . . . .	986291	302-303	.6
LAMP - Back Up - Chevelle - Station Wagon and El Camino .	986292	304-305	.6
LAMP - Back Up - Chevy II Except Station Wagon & 4 Spd. . .	986289	306-307	.6
LAMP - Back Up - Chevy II - Station Wagon . . . . .	986290	308-310	.6
LAMP - Back Up - Adapter for 4 Spd. Corvair . . . . .	986262	311	-
LAMP - Back Up - Corvair Series 10100 and 10300 . . . . .	986261	312-313	1.4
LAMP - Back Up - Truck - All Pick Up and Panels . . . . .	985970	314-318	.8
LAMP - Cab Clearance . . . . .	985977	319-323	.8
LAMP - Courtesy - All Except Truck and Corvette . . . . .	986287	324-328	.5
LAMP - Dome - Corvair 95 . . . . .	988346	329-330	1.0
LAMP - Glove Compartment - All Except Truck and Corvette .	986288	331-334	.2
LAMP - LUGGAGE Compartment - All Except Truck and Corvette . . . . .	986043	335-339	.3
LAMP - Underhood - All Except Truck and Corvette . . . . .	986042	340-342	.3
LIGHTER - Cigarette - Truck . . . . .	986343	343-344	.2
LOCK - Rear Compartment - Chevrolet 6 Passenger Station Wagon . . . . .	986263	345	.5
LOCK - SPARE TIRE - Corvair . . . . .	986026	346	.2
MIRROR - Outside - Rear View - Chevrolet . . . . .	986272	347	.3
MIRROR - Outside - Rear View - Chevelle, Chevy II, Corvair, and Corvair 95 . . . . .	986046	348-349	.3
MIRROR - Outside - Rear View - Remote Control - Chevrolet	986260	350	.8
MIRROR - Outside - Rear View - Remote Control - Chevelle, Chevy II & Corvair . . . . .	986049	351-352	.8
MIRROR - Extendable - Rear View - 5 x 7 Inch . . . . .	985823	353-354	.5
MIRROR - Deluxe - Rear View - 7 x 16" Truck Exc. Tilt Cab .	985780	355-356	.8
MIRROR - Deluxe - Rear View - 7 x 16" Tilt Cab . . . . .	985283	357-358	.8
MIRROR - Deluxe - Rear View - 7 1/2 x 10 1/2" - Truck . . .	986014	359	.8
MIRROR - Deluxe - Rear View - 6 x 11" - Truck . . . . .	985771	360-361	.8
MIRROR - Deluxe - Rear View - 6 x 11" - Chevy Van . . . . .	985911	362	.8
MOULDING - Body Sill - Chevelle 13300 and 13400 Series . .	985881	363	.7
MOULDING - Hood Panel Crown - Chevrolet . . . . .	986188	364	.3
MOULDING - Wheel Housing - Bel Air and Biscayne . . . . .	986335	365	.5
OPENER - Automatic Trunk - Chevrolet, Chevelle & Chevy II .	986136	366-373	1.0
RADIO & ANTENNA - AM-FM Chevrolet . . . . .	986101	374-378	1.4
RADIO & ANTENNA - Push Button & Manual Chevrolet .	986096-986099	379-382	1.4
RADIO & ANTENNA - AM-FM - Corvette . . . . .	986281	383-390	5.2
RADIO & ANTENNA - AM-FM - Chevelle . . . . .	986203	391-393	1.4
RADIO & ANTENNA - Push Button & Manual - Chevelle . . . . .	986201-986202	394-396	1.4
RADIO & ANTENNA - AM-FM - Push Button & Manual - Chevy II . . . . .	986248-986250-986252	397-400	1.6
RADIO & ANTENNA - AM-FM - Corvair . . . . .	986118	401-403	1.6




## ALPHABETICAL INDEX (Continued)

Description	Part No.	Page No.	Flat Rate Hours
RADIO & ANTENNA - Push Button & Manual - Corvair . . .	986113-986116	404-406	1.6
RADIO & ANTENNA - Manual - Truck Except Tilt Cab . . . . .	986338	407-416	1.6
RADIO & ANTENNA - Chevrolet Tilt Cab . . . . .	986338	417-421	1.6
RADIO & ANTENNA - Chevy Van . . . . .	986339	422-423	-
SAFETYLIGHT - Remote Control - Chevrolet . . . . .	986279	424-426	1.5
SAFETYLIGHT - L.H. - Chevelle . . . . .	985807	427-429	1.0
SAFETYLIGHT - L.H. - Truck . . . . .	985861	430-432	1.0
SAFETYLIGHT - Chevy Van & Corvair 95 . . . . .	985932	433-435	1.0
SIGNAL - Parking Brake - Chevrolet . . . . .	986246	436	.4
SIGNAL - Parking Brake - Chevelle . . . . .	985901	437	.4
SIGNAL - Parking Brake - Chevy II . . . . .	985248	438	.3
SIGNAL - Parking Brake - Corvair . . . . .	986209	439	.3
SPEAKER - Rear Seat - All Sedans - Chevrolet . . . . .	986257	440-441	1.0
SPEAKER - Rear Seat - Chevrolet Sport Coupe & Conv. . . . .	986258	442-444	1.5
SPEAKER - Rear Seat - Chevrolet Station Wagon . . . . .	986259	445-447	1.5
SPEAKER - Rear Seat - Chevelle Exc. Sta. Wag. & El Camino	986286	448-450	1.0
SPEAKER - Rear Seat - Chevy II Exc. Convertibles . . . . .	985493	451-454	.9
SPEAKER - Rear Seat - Corvair Exc. Convertible . . . . .	986218	455-456	.7
SPEED & CRUISE CONTROL - Chevrolet 283 & 327 Eng. . . . .	986322	457-462	1.2
SPEED & CRUISE CONTROL - Chevelle 283 & 327 Eng. . . . .	986334	463-469	1.2
SPRING - Auxiliary - Chevrolet Truck C10-20 . . . . .	985767	470-471	1.0
SPRING - Auxiliary - Chevrolet Truck 50 thru 80 Series . . . . .	985515-985516	472	1.0
STEP - Rear Bumper - Pick Up & Fleetside Truck . . . . .	986027	473-475	-
STEP - Rear Bumper - Fleetside Truck . . . . .	986028	476-478	-
STEP - Side Panel . . . . .	988423	479	.8
STEREO MULTIPLEX (Instructions Not Available at Publication Date)			
SWITCH - Hazard Flasher . . . . .	986293-986294	480-490	.5
TACHOMETER - All Except Corvair & Corvette . . . . .	986325	491-494	.5
VENTSHADES - Chevrolet - Chevelle - Chevy Van & Greenbrier . . . . .	ALL	495	.3
VENTSHADES - Chevy II . . . . .	ALL	496	.3
VENTSHADES - Truck . . . . .	985704	497	.3
VISOR R.H. SUN - All Standard Cabs & Panel Truck . . . . .	985887	498	.3
VISOR R.H. SUN - Truck Tilt Cab . . . . .	985753	499	.3
VISOR R.H. SUN - Greenbrier . . . . .	985900	500	.3
WASHER - Windshield - Chevrolet . . . . .	986066	501-503	.6
WASHER - Windshield - Chevelle . . . . .	986029	504-506	.6
WASHER - Windshield - Chevy II . . . . .	986137	507-508	.6
WASHER - Windshield - Corvair . . . . .	986048	509-510	.6
WASHER - Windshield - Truck . . . . .	986183	511-514	1.0
WASHER - Windshield - Greenbrier . . . . .	986180	515-517	1.0
WASHER - Windshield - Chevy Van . . . . .	986181	518-520	1.0
WASHER - Windshield - Tilt Cab . . . . .	986182	522-525	1.0



**AIR CONDITIONER COMPRESSOR INSTALLATION  
ALL FOUR AND SIX ENGINES**



**FIG. 1** COMPRESSOR & BRACKETS

**NOTE** This instruction is to be used in conjunction with instruction sheets provided in Air Conditioning Unit.

**STEP 1** (L-4 & 230 L-6 ENGINE) REMOVE & RETAIN NO. 1 & 2 SPARK PLUG WIRE, COIL & ATTACHING PARTS.

**STEP 2** (230 L-6 ENGINE) REMOVE & DISCARD NO. 3, 4, 5 & 6 SPARK PLUG WIRES & COIL TO DISTRIBUTOR (HI-TENSION) WIRE.

**STEP 3** (L-4 ENGINE) REMOVE & DISCARD NO. 3 & 4 SPARK PLUG WIRES & COIL TO DISTRIBUTOR


(HI-TENSION) WIRE.

**STEP 4** LOOSELY ASSEMBLE REAR MOUNTING BRACKET TO COMPRESSOR WITH PROVIDED ATTACHING PARTS. SEE FIG. 1.

**STEP 5** SECURE FRONT MOUNTING BRACKET TO COMPRESSOR AT L.H. UPPER & LOWER HOLES WITH ATTACHING PARTS PROVIDED. SEE FIG. 1.

**STEP 6** ATTACH CLIP TO FRONT OF COMPRESSOR WITH ATTACHING PARTS PROVIDED. SEE FIG. 1. **NOTE** Outboard end of clip must loop over edge of front bracket.





**STEP 1** INSTALL COMPRESSOR SUPPORT & MOUNTING PLATE TO ENGINE WITH ATTACHING PARTS PROVIDED. SEE FIG. 1. **NOTE** (Except Chevy L-6) Attach provided battery ground wire to front of support with front attaching bolt.

**STEP 2** ATTACH COIL TO MOUNTING PLATE WITH RETAINED ATTACHING PARTS. SEE VIEW A.

**STEP 3** INSTALL COMPRESSOR TO SUPPORT WITH PROVIDED ATTACHING PARTS. SEE FIG. 1.

**STEP 4** (EXCEPT CHEVY L-6 ENGINE) ATTACH COMPRESSOR GROUND WIRE TO COMPRESSOR & FRONT BRACKET WITH ATTACHING PARTS PROVIDED & FLAT WASHER PROCURED FROM DEALER'S STOCK. SEE FIG. 1.

**STEP 5** (CHEVY L-6 ENGINE) ATTACH COMPRESSOR GROUND WIRE & BATTERY GROUND

CABLE TO COMPRESSOR & FRONT BRACKET WITH ATTACHING PARTS PROVIDED. SEE FIG. 1.


**STEP 6** INSERT SHIMS BETWEEN REAR BRACKET & COMPRESSOR AS REQUIRED TO TAKE UP SLACK. TIGHTEN BOLTS. SEE FIG. 1.

**STEP 7** (EXCEPT 292 CU. IN. ENGINE) RE-INSTALL RETAINED NO. 1 & 2 SPARK PLUG WIRES. SEE VIEW A OR B.

**STEP 8** (EXCEPT 292 ENGINE) INSTALL NO. 3, 4, 5 & 6 SPARK PLUG WIRES PROVIDED TO ENGINE & CLIP WITH PROVIDED RETAINER AS SHOWN, OR INSTALL NO. 3 & 4 WIRES TO L-4 ENGINE. SEE VIEW A OR B.

**STEP 9** (EXCEPT 292 ENGINE) INSTALL PROVIDED HI-TENSION WIRE (COIL TO DISTRIBUTOR) SEE VIEW A OR B.





#### L-4 ENGINE WITHOUT POWER STEERING

**STEP 1** REMOVE & DISCARD EXISTING GENERATOR BELT.

**STEP 2** INSTALL CRANKSHAFT PULLEY (PROCURED FROM DEALER'S STOCK) TO EXISTING HARMONIC BALANCER WITH PROVIDED SCREWS. SEE FIG. 1.

**STEP 3** REMOVE & DISCARD EXISTING FAN & FAN PULLEY, BUT RETAIN ATTACHING PARTS.


**STEP 4** INSTALL PROVIDED FAN & FAN PULLEY

(PULLEY WITH SHORTEST HUB) WITH RETAINED ATTACHING PARTS. SEE FIG. 1. **NOTE** Discard fan pulley with longest hub.

**STEP 5** INSTALL GENERATOR BELT (PROCURED FROM DEALER'S STOCK) ON REAR PULLEYS. INSTALL PROVIDED COMPRESSOR BELT ON FRONT PULLEYS. SEE SCHEMATIC IN FIG. 1.

**NOTE** Adjust compressor on support until belt is tight, then secure nuts at pivot bolts & clamping bolt. See Fig. 1, Sheet 2.





#### L-6 ENGINE WITHOUT POWER STEERING

**NOTE** For 292 cu.in. Engine, Follow instructions provided in Air Conditioning Pulley & Belt Adapter Unit.

**STEP 1** REMOVE & DISCARD EXISTING GENERATOR BELT.

**STEP 2** INSTALL PROVIDED CRANKSHAFT PULLEY TO EXISTING HARMONIC BALANCER WITH PROVIDED SCREWS. SEE FIG. 1.

**STEP 3** (EXCEPT CHEVELLE) REMOVE & DISCARD EXISTING FAN, SPACER & FAN PULLEY, BUT RETAIN ATTACHING PARTS. INSTALL PROVIDED FAN & FAN PULLEY (FAN PULLEY WITH SHORTEST HUB) & SPACER (CHEVROLET) WITH RETAINED ATTACHING PARTS. SEE FIG. 1.  
**NOTE** Discard Fan Pulley with longest hub. Also discard Spacer except when concerned with Chevrolet.


**STEP 4** (CHEVELLE) REMOVE & DISCARD EXISTING FAN, SPACER & FAN PULLEY, BUT RE-

TAIN ATTACHING PARTS. INSTALL PROVIDED FAN & FAN PULLEY (FAN PULLEY WITH LONGEST HUB) WITH RETAINED ATTACHING PARTS. SEE FIG. 1. **NOTE** Discard Fan Pulley with shortest hub.

**STEP 5** (EXCEPT CHEVY) REMOVE & DISCARD EXISTING GENERATOR FAN PULLEY ASM., BUT RETAIN ATTACHING PARTS. INSTALL PROVIDED GENERATOR PULLEY & PULLEY FAN WITH RETAINED ATTACHING PARTS. SEE FIG. 1.  
**NOTE** Discard provided Pulley & Fan when concerned with Chevy.

**STEP 6** INSTALL PROVIDED GENERATOR BELT ON REAR PULLEYS. INSTALL PROVIDED COMPRESSOR BELT ON FORWARD PULLEYS. SEE SCHEMATIC IN FIG. 1. **NOTE** Adjust compressor on support until belt is tight, then secure nuts at pivot bolts & clamping bolt. SEE FIG. 1, SHEET 2.





#### L-6 ENGINE WITH POWER STEERING

**NOTE** For 292 cu. in. engine follow instructions provided in Air Conditioning Pulley & Belt Adapter Unit.

**STEP 1** REMOVE & DISCARD EXISTING POWER STEERING & GENERATOR BELTS.

**STEP 2** REMOVE & DISCARD EXISTING CRANKSHAFT PULLEYS & ATTACHING PARTS.


**STEP 3** INSTALL PROVIDED DOUBLE TRACK CRANKSHAFT PULLEY TO EXISTING HARMONIC BALANCER WITH PROVIDED SCREW. SEE FIG. 1.

**STEP 4** REMOVE & DISCARD EXISTING FAN, SPACER (IF EXISTING) & FAN PULLEY. RETAIN ATTACHING PARTS.

**STEP 5** (EXCEPT CHEVELLE) INSTALL PROVIDED FAN, SPACER (CHEVROLET ONLY) & SHORT HUB FAN PULLEY WITH RETAINED ATTACHING PARTS. SEE FIG. 1.

**STEP 6** (CHEVELLE) INSTALL PROVIDED FAN & LONG HUB FAN PULLEY WITH RETAINED ATTACHING PARTS. SEE FIG. 1. **NOTE** Discard unused pulleys. They are for other models.





**NOTE** For 292 cu. in. engine follow instructions provided in Air Conditioning Pulley & Belt Adapter Unit.

**STEP 1** (EXCEPT CHEVY) REMOVE & DISCARD EXISTING GENERATOR FAN PULLEY. RETAIN ATTACHING PARTS. **NOTE** Chevy uses existing generator fan pulley.

**STEP 2** (EXCEPT CHEVY) INSTALL PROVIDED TRIPLE TRACK GENERATOR PULLEY, SPACER, & GENERATOR FAN WITH RETAINED ATTACHING PARTS. SEE FIG. 1. **NOTE** With 62 amp. generator install spacer in front of generator pulley.

**STEP 3** (CHEVY) REMOVE & DISCARD EXISTING POWER STEERING BRACE & GENERATOR BRACE.





RETAIN ATTACHING PARTS.

**STEP 4** (CHEVY) INSTALL PROVIDED GENERATOR BRACE & POWER STEERING BRACE WITH RETAINED ATTACHING PARTS. SEE FIG. 1.

**STEP 5** INSTALL PROVIDED GENERATOR BELT ON REAR PULLEYS, PROVIDED COMPRESSOR BELT ON CENTER PULLEYS & PROVIDED POWER STEERING BELT ON FORWARD PULLEYS. SEE SCHEMATIC IN FIG. 1.

**STEP 6** ADJUST COMPRESSOR ON SUPPORT UNTIL BELT IS TIGHT, THEN SECURE NUTS AT PIVOT BOLTS & CLAMPING BOLT. SEE FIG. 1, SHEET 2.





**VEHICLE WITH L-4 OR L-6 ENGINE (EXCEPT TRUCK)**

**L-4 ENGINE**

**STEP 1** DISCONNECT POSITIVE VENT HOSE & RETAIN CLAMP. REMOVE & DISCARD ELBOW FROM INTAKE MANIFOLD. SEE FIG. 1.

**STEP 2** INSTALL TEES & PLUG (PROCURED FROM DEALERS STOCK) WITH PROVIDED VALVE & POSITION AS SHOWN. SEE FIG. 1.

**STEP 3** RE-INSTALL POSITIVE VENT HOSE WITH RETAINED CLAMP. SEE FIG. 1.

**L-6 ENGINE**

**STEP 4** REMOVE & DISCARD EXISTING PLUG FROM INTAKE MANIFOLD. SEE FIG. 2.

**STEP 5** INSTALL PROVIDED REDUCER & VALVE (CARB AIR BLEED). SEE FIG. 2.

**L-6 ENGINE WITH POWER BRAKES**

**STEP 6** DISCONNECT POWER BRAKE HOSE FROM INTAKE MANIFOLD & RETAIN CLAMP. SEE FIG. 3 OR 4.

**STEP 7** REMOVE & DISCARD EXISTING POWER BRAKE ELBOW FROM INTAKE MANIFOLD. SEE FIG. 3 OR 4.



**STEP 8** INSTALL PROVIDED TEE CONNECTOR & VALVE (CARB AIR BLEED). SEE FIG. 3 OR 4.

**STEP 9** INSTALL HOSE CONNECTOR TO TEE CONNECTOR & ATTACH POWER BRAKE HOSE WITH RETAINED CLAMP. SEE FIG. 3 OR 4.

**NOTE** Discard any parts not used, they are for other models. Continue with steps in Air Conditioning Instruction.



**AIR CONDITIONER COMPRESSOR INSTALLATION—ALL V-8 ENGINES  
CHEVROLET—CHEVELLE—CHEVY II—CHEVROLET TRUCK  
EXCEPT 396 CUBIC INCH ENGINE**



**STEP 1** REMOVE POSITIVE VENT HOSE FROM CHECK VALVE. REMOVE & RETAIN EXISTING POSITIVE VENT CHECK VALVE. DISCARD EXISTING CONNECTOR OR ELBOW.

**STEP 2** INSTALL PROVIDED TEE, REDUCER & VALVE ASM. (CARB. AIR BLEED). SEE FIG. 1.



**STEP 3** INSTALL RETAINED POSITIVE VENT CHECK VALVE OR PROVIDED CONNECTOR (USED WITH CLOSED POSITIVE VENTILATION ONLY). SEE FIG. 1.

**STEP 4** ATTACH EXISTING HOSES AS SHOWN. SEE FIG. 1.

**STEP 5** ATTACH REAR MOUNTING BRACKET TO COMPRESSOR WITH PROVIDED ATTACHING PARTS. DO NOT TIGHTEN BOLTS AT THIS TIME. SEE FIG. 2.

**STEP 6** ATTACH FRONT MOUNTING BRACKET & COMPRESSOR GROUND WIRE TO COMPRESSOR. WITH PROVIDED ATTACHING PARTS & FLAT WASHER PROCURED FROM DEALER'S STOCK. SEE FIG. 2.





**STEP 1** REMOVE & DISCARD (2) MANIFOLD BOLTS. INSTALL PROVIDED STUD. ATTACH REAR SUPPORT TO EXHAUST MANIFOLD WITH PROVIDED ATTACHING PARTS. SEE FIG. 1.

**STEP 2** REMOVE & DISCARD EXISTING NIPPLE FROM WATER PUMP HOUSING. INSTALL PROVIDED NIPPLE. SEE FIG. 1.


**STEP 3** ATTACH FRONT SUPPORT & EXISTING

BATTERY GROUND CABLE TO ENGINE WITH PROVIDED ATTACHING PARTS. SEE FIG. 1.

**STEP 4** ATTACH COMPRESSOR BRACKETS & CLIP TO SUPPORTS WITH PROVIDED ATTACHING PARTS. SEE FIG. 2.

**STEP 5** INSERT SHIM BETWEEN REAR BRACKETS & COMPRESSOR. USE QUANTITY REQUIRED TO TAKE UP SLACK & TIGHTEN BOLTS. SEE FIG. 2.





**FIG. 1** COMPRESSOR BRACES ("283" & "327" ENGINE-ALL VEHICLES EXCEPT CHEVY & TRUCK)

**STEP 1** REMOVE BOLT & L. WASHER FROM ENGINE END OF EXISTING GENERATOR BRACE. DISCARD BOLT BUT RETAIN L. WASHER.



**STEP 2** ATTACH FRONT BRACE TO ENGINE & COMPRESSOR. SEE FIG. 1. **NOTE** Do not tighten nut at slotted end of brace until compressor belt is installed.

**STEP 3** ATTACH REAR BRACE TO COMPRESSOR WITH PROVIDED ATTACHING PARTS. SEE FIG. 1.

**STEP 4** REMOVE & DISCARD (2) INLET MANIFOLD BOLTS. ATTACH REAR BRACE SUPPORT TO INLET MANIFOLD WITH PROVIDED BOLTS. SEE FIG. 1.

**STEP 5** COMPLETE ATTACHMENT, BY LOOSELY ATTACHING REAR BRACE TO SUPPORT. SEE FIG. 1. **NOTE** Do not tighten bolt at slotted end of brace until compressor belt is installed.





**STEP 1** REMOVE TWO (2) FORWARD MANIFOLD BOLTS. DISCARD FRONT BOLT. INSTALL PROVIDED BOLT LOCK USING SPL. STUD, P. WASHER & RETAINED BOLT. SEE FIG. 1.

**STEP 2** ATTACH ADAPTER TO ENGINE AT SPECIAL STUD WITH PROVIDED ATTACHING PARTS. INSTALL PROVIDED "U" BOLTS AROUND MANIFOLD & THRU ADAPTER. SECURE WITH PROVIDED L. WASHERS & NUTS. SEE FIG. 1.


**STEP 3** ATTACH COMPRESSOR SUPPORT TO ADAPTER WITH

PROVIDED ATTACHING PARTS. SEE FIG. 2.



**STEP 4** ATTACH FRONT & REAR MOUNTING BRACKETS TO COMPRESSOR. WITH PROVIDED ATTACHING PARTS. SEE FIG. 2.

**STEP 5** INSERT BUSHINGS INTO FRONT & REAR BRACKETS. ATTACH COMPRESSOR TO SUPPORT WITH PROVIDED ATTACHING PARTS. SEE FIG. 2.





**FIG. 1** RADIATOR HOSE (409 ENGINE)



**FIG. 2** COMPRESSOR & SUPPORT MOUNTING (409 ENGINE)

**STEP 1** REMOVE & DISCARD EXISTING RADIATOR HOSE. RETAIN EXISTING CLAMPS.

**STEP 2** INSTALL PROVIDED RADIATOR HOSE & SECURE WITH RETAINED CLAMPS. SEE FIG. 1.

**STEP 3** REMOVE & DISCARD EXISTING OIL LEVEL TUBE & GAUGE ASM. REPLACE EXISTING NUT & L. WASHER.

**STEP 4** ATTACH PROVIDED OIL LEVEL TUBE & GAUGE ASM. TO EXHAUST MANIFOLD WITH EXISTING MANIFOLD BOLT. SEE FIG. 2.

**STEP 5** SUB-ASSEMBLE FRONT & REAR BRACKETS TO COMPRESSOR WITH PROVIDED ATTACHING PARTS. SEE FIG. 2.

**STEP 6** REMOVE & RETAIN EXISTING ENGINE BOLT. ATTACH REAR SUPPORT TO EXISTING MANIFOLD STUD WITH PROVIDED NUT & L. WASHER.

SECURE REAR SUPPORT TO ROCKER ARM COVER WITH RETAINED ENGINE BOLT. SEE VIEW A.

**NOTE** Before attaching front support to engine, install provided bolt & spl. washer loosely at slotted hole.

**STEP 7** ATTACH FRONT SUPPORT TO ENGINE WITH PROVIDED ATTACHING PARTS. SEE FIG. 2.


**STEP 8** ATTACH FRONT SUPPORT TO REAR SUPPORT WITH PROVIDED ATTACHING PARTS. SEE VIEW A.

**STEP 9** ATTACHING EXISTING BATTERY GROUND CABLE TO FRONT SUPPORT WITH PROVIDED ATTACHING PARTS. SEE FIG. 2.

**STEP 10** ATTACH COMPRESSOR & BRACKET ASM. TO COMPRESSOR FRONT SUPPORT WITH PROVIDED ATTACHING PARTS. SEE FIG. 2.

**NOTE** Do not tighten nuts & bolts at pivot until compressor belt is installed.





**FIG. 1 COMPRESSOR SUPPORT MOUNTING ("283" & "327" ENGINE-TRUCK)**

**STEP 1** (L50 & C-L-M60) REMOVE & RETAIN OIL LEVEL TUBE & GAUGE. SEE FIG. 1.

**STEP 2** REMOVE & REPLACE (2) R. H. FRONT BOLTS ON INTAKE MANIFOLD WITH BOLT STUDS PROVIDED. SEE VIEW A.

**STEP 3** REMOVE & REPLACE (2) FRONT BOLTS ON R. H. EXHAUST MANIFOLD WITH PROVIDED BOLT LOCK & STUDS. SEE FIG. 1.

**STEP 4** REMOVE & DISCARD THIRD BOLT ON R. H. EXHAUST MANIFOLD & UPPER R. H. BOLT ON WATER PUMP. SEE FIG. 1.

**STEP 5** REMOVE & REPLACE CARBURETOR FUEL PIPE WITH PROVIDED PIPE. SEE FIG. 1.

**STEP 6** SUB-ASSEMBLE HINGE BRACKET TO SUP-

PORT TO DIMENSIONS SHOWN WITH ATTACHING PARTS PROVIDED. SEE FIG. 1.


**STEP 7** PLACE SUPPORT OVER INTAKE & EXHAUST MANIFOLD STUDS & INSTALL WITH PROVIDED ATTACHING PARTS. SEE FIG. 1.

**NOTE** Hand bend fuel pipe to clear compressor support as shown. See Fig. 1 & View A.

**STEP 8** (L MODELS) BEND RETAINED OIL LEVEL TUBE BRACKET AS SHOWN. LOCATE, CENTER-PUNCH & DRILL HOLE IN BRACKET TO DIMENSIONS SHOWN. SEE VIEW B.

**STEP 9** (L50 & C-L-M60) REINSTALL RETAINED OIL LEVEL TUBE & GAUGE WITH PROVIDED ATTACHING PARTS. SEE FIG. 1.





**FIG. 1** COMPRESSOR MOUNTING ("283" & "327" ENGINE-TRUCK)

**STEP 1** ATTACH REAR MOUNTING BRACKET COM-  
PRESSOR WITH PROVIDED SCREWS. SEE VIEW A.

**CAUTION** Do not remove shipping straddle plate or  
plugs until immediately before assembling of com-  
pressor hoses to compressor to prevent entry of air  
into system.


**STEP 2** ATTACH FRONT BRACKET TO COMPRESS-

OR WITH PROVIDED SCREWS. SEE FIG. 1.

**STEP 3** ATTACH FRONT & REAR COMPRESSOR  
BRACKETS TO HINGE BRACKET WITH PROVIDED  
ATTACHING PARTS. SEE FIG. 1.

**STEP 4** ATTACH FRONT BRACKET TO SUPPORT  
WITH PROVIDED ATTCHING PARTS. SEE FIG. 1.





**FIG. 1** FAN, BELTS & PULLEYS ('283" & "327" ENGINES-ALL EXCEPT TRUCK)

**STEP 1** REMOVE & DISCARD EXISTING GENERATOR BELT.

**STEP 2** REMOVE & DISCARD CRANKSHAFT & FAN PULLEYS BUT RETAIN ATTACHING PARTS. ALSO RETAIN SPACER ON "283" ENGINE. DISCARD FAN ON "283" ENGINE, BUT RETAIN FAN & CLUTCH ON "327" ENGINE.


**STEP 3** INSTALL PROVIDED CRANKSHAFT & FAN PULLEYS, PROVIDED FAN & EXISTING SPACER

(ON "283" ENGINE) OR EXISTING FAN & CLUTCH (ON "327" ENGINE) WITH EXISTING ATTACHING PART. SEE FIG. 1.

**STEP 4** INSTALL PROVIDED GENERATOR BELT ON REAR PULLEYS & COMPRESSOR BELT ON FORWARD PULLEYS. SEE SCHEMATIC IN FIG. 1.

**NOTE** Adjust compressor on support until belt is tight then secure nuts at pivot bolts & clamping bolts. See COMPRESSOR MOUNTING SHEETS.





**FIG. 1** FAN, BELTS & PULLEYS ('283" & "327" ENGINES WITH POWER STEERING-ALL EXCEPT TRUCK)

**STEP 1** REMOVE & RETAIN EXISTING POWER STEERING BELT. DISCARD GENERATOR BELT.

**STEP 2** REMOVE EXISTING "POWER STEERING" CRANKSHAFT PULLEY & CONVENTIONAL CRANKSHAFT PULLEY. DISCARD CONVENTIONAL PULLEY, BUT RETAIN "POWER STEERING" PULLEY & ATTACHING PARTS.

**STEP 3** REMOVE & DISCARD EXISTING FAN PULLEY BUT RETAIN ATTACHING PARTS. RETAIN SPACER ON "283" ENGINE. DISCARD FAN ON "283" ENGINE. RETAIN FAN & CLUTCH ON "327" ENGINE.


**STEP 4** INSTALL PROVIDED & EXISTING CRANK-

SHAFT PULLEYS WITH EXISTING ATTACHING PARTS. SEE FIG. 1.

**STEP 5** INSTALL PROVIDED FAN PULLEY, EXISTING FAN & CLUTCH (ON "327" ENGINE) OR PROVIDED FAN & EXISTING SPACER (ON "283" ENGINE) WITH EXISTING PARTS. SEE FIG. 1.

**STEP 6** INSTALL PROVIDED GENERATOR BELT ON REAR PULLEYS, COMPRESSOR BELT ON CENTER PULLEYS & EXISTING POWER STEERING BELT ON FORWARD PULLEY. SEE SCHEMATIC IN FIG. 1. **NOTE** Adjust compressor on support until belt is tight then secure nuts at pivot bolts & clamping bolts. See COMPRESSOR MOUNTING SHEETS.





**FIG. 1** FAN, BELTS & PULLEYS ("409" ENGINE WITHOUT POWER STEERING)

**STEP 1** REMOVE & DISCARD EXISTING IDLER ASM., BELT & ATTACHING PARTS.

**STEP 2** REMOVE & DISCARD EXISTING GENERATOR BELT, PULLEY & GENERATOR FAN. RETAIN ATTACHING PARTS.


**STEP 3** REMOVE & DISCARD EXISTING WATERPUMP & CRANKSHAFT PULLEYS BUT RETAIN ATTACHING PARTS. RETAIN EXISTING FAN & CLUTCH ASM.

**STEP 4** INSTALL PROVIDED GENERATOR FAN

& PULLEY, WATERPUMP PULLEY (2 TRACK), CRANKSHAFT PULLEY & EXISTING FAN & CLUTCH ASM. WITH RETAINED ATTACHING PARTS. SEE FIG. 1. **NOTE** Discard (3 track) waterpump pulley.

**STEP 5** INSTALL PROVIDED GENERATOR BELT ON REAR PULLEYS & PROVIDED COMPRESSOR BELT ON FORWARD PULLEYS. SEE SCHEMATIC IN FIG. 1. **NOTE** Adjust compressor on support until belt is tight, then secure nuts at pivot bolt & clamping bolt. SEE COMPRESSOR MOUNTING SHEET.





**FIG. 1** FAN, BELTS & PULLEYS ("409" ENGINE WITH POWER STEERING)

**STEP 1** REMOVE POWER STEERING BELT & PULLEY. DISCARD PULLEY & BELT BUT RETAIN ATTACHING PARTS.

**STEP 2** REMOVE & DISCARD EXISTING GENERATOR BELT, PULLEY & GENERATOR FAN. RETAIN ATTACHING PARTS.

**STEP 3** REMOVE & DISCARD EXISTING WATERPUMP & CRANKSHAFT PULLEYS BUT RETAIN ATTACHING PARTS. RETAIN EXISTING FAN & CLUTCH ASM.

**STEP 4** INSTALL PROVIDED POWER STEERING PULLEY WITH RETAINED ATTACHING PARTS. SEE FIG. 1.

**STEP 5** INSTALL PROVIDED GENERATOR FAN & PULLEY, WATERPUMP PULLEY (3 TRACK), CRANKSHAFT PULLEYS & EXISTING FAN & CLUTCH ASM. **NOTE** Discard (2 track) waterpump pulley.

**STEP 6** INSTALL PROVIDED GENERATOR BELT ON REAR PULLEYS, COMPRESSOR BELT ON CENTER PULLEYS & POWER STEERING BELT ON FORWARD PULLEYS. SEE SCHEMATIC IN FIG. 1. **NOTE** Adjust compressor on support until belt is tight, then secure nuts at pivot bolt & clamping bolt. SEE COMPRESSOR MOUNTING SHEET.